












Light Kit Installation





41526-01 4/05/2011












9 Connect plugs.



10 Reinstall screws.



11 Install glass.



12 Install bulbs.



**READ ENTIRE TEXT CAREFULLY BEFORE BEGINNING
INSTALLATION AND SAVE THESE INSTRUCTIONS.**

WARNING!

- To reduce the risk of electrical shock and fire, install this light kit only on Hunter suspended ceiling fans.
- To avoid possible electrical shock, before installing light fixtures, disconnect power by turning off the circuit breakers both to the outlet box and to its associated wall switch location. If you cannot lock the circuit breakers in the off position, securely fasten a prominent warning device, such as a tag, to the service panel.
- Connect house wiring to the fan before attaching the light fixture to the fan.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, you should use a qualified electrician. Professional installation is recommended.
- Suitable for indoors at 40° C.

NOTE: WHEN REPLACING BULBS, REPLACE WITH TYPE A-19 (MAX 60W).

Troubleshooting

**Problem:**

Nothing happens, light does not come on.

Solution:

1. Restore power to the fan.
2. Pull light chain one or two times.
3. Make sure bulbs are properly installed and filament is not blown.
4. Make sure plug connectors are properly connected and locked together.
5. Check light power lead at the ceiling.
6. Contact your local Hunter dealer.

**Problem:**

Glass rattles.

Solution:

1. Check rubber silencer bands around glass rims.
2. Tighten thumbscrews.
3. Contact your local Hunter dealer.